




U-192
WALKING FOOT
(OUTSIDE)




U-192HA
WALKING FOOT
(OUTSIDE)




U-192H 1/8"
U-192J 5/32"
U-192L 3/16"
U-192G 7/32"
U-192K 1/4"
U-192M 5/16"
U-192N 3/8"
WALKING FOOT
(OUTSIDE)




U-193K
PRESSER FOOT
(INSIDE)




U-193
PRESSER FOOT
(INSIDE)




U-193HA
PRESSER FOOT
(INSIDE)



U-192HC 1/8"
U-192JC 5/32"
U-192LC 3/16"
U-192GC 7/32"
U-192KC 1/4"
U-192MC 5/16"
U-192NC 3/8"
WALKING FOOT
(OUTSIDE)




U-193K
PRESSER FOOT
(INSIDE)




U-192P
WALKING FOOT
(OUTSIDE)



U-192Q
WALKING FOOT
(OUTSIDE)




U-192R
WALKING FOOT
(OUTSIDE)




U-192T
WALKING FOOT
(OUTSIDE)




U-192HW 1/8"
U-192LW 3/16"
U-192GW 7/32"
U-192KW 1/4"
WALKING FOOT (OUTSIDE)




U-193P
PRESSER FOOT
(INSIDE)




U-193Q
PRESSER FOOT
(INSIDE)




U-193R
PRESSER FOOT
(INSIDE)




U-193T
PRESSER FOOT
(INSIDE)




U-193KW
PRESSER FOOT
(INSIDE)




U-192Y
WALKING FOOT
(OUTSIDE)




U-31
WALKING FOOT
(OUTSIDE)




U-31A
WALKING FOOT
(OUTSIDE)




U-31F
WALKING FOOT
(OUTSIDE)




U-31L
WALKING FOOT
(OUTSIDE)




U-193Y
PRESSER FOOT
(INSIDE)




U-30
PRESSER FOOT
(INSIDE)



U-30A
PRESSER FOOT
(INSIDE)



U-30F
PRESSER FOOT
(INSIDE)



U-30L
PRESSER FOOT
(INSIDE)